

Service MEMO

Saks Fifth Ave

Quantum XTW

RE: Quantum Series RFID De-activation Instructions

LAST REVISED: 10/8/2020

1. Turn Machine OFF then ON
2. During boot cycle hold "mode" button (bottom left) and "rabbit" button (top right), wait until password screen appears.
3. Enter "263" password (Use "plus" button to cycle numbers and "rabbit" button to rotate through characters. Hit "home" button once password is entered)
4. Set "Security Length" Parameter to "0000M" to disable the security for the machine, and consequently remove any 601 error codes. (Use the "rabbit"/"turtle" buttons to navigate up/down the menu, and the "minus" button to decrease the security length to 0000M)
5. Cycle the power off/on to save the settings